



A bit of background

Marmox Multiboard can be used for many applications. Its premium quality, reinforced structure means it can be used for waterproofing walls, floors & Ceilings while giving additional insulating properties.

Additionally the multi-board can be used for rigid boarding in partitions, wet rooms, loft conversions and performs as a great underlay for heated mats increasing overall efficiency.

Your Itinerary

In order to complete this how to guide, you're going to need the following product:

Marmox Multiboard	Marmox Washers
Marmox Reinforcing Tape	Marmox Waterproof Tape

Also

We suggest that you use the following accessories & safety equipment when undertaking this job:

[4Trade Safety Glasses](#)

[4Trade Super Grip Safety Gloves](#)

[4 Trade Respirator Mask](#)

Prior to installation it's important to ensure you are installing in a clean, dry environment that is well ventilated.

We strongly advise that you use Personal Protective Equipment (PPE) listed above.

Floor - adhesive



Step 1

Use a floor trowel to comb the adhesive onto the floor.



Step 2

Lay the Marmox Multiboard down onto the adhesive and push firmly.



Step 3

You can use Marmox Multibond for further waterproofing or in really wet areas use Marmox Self Adhesive Waterproof Tape.