



A bit of background

Marmox Multiboard can be used for many applications. Its premium quality, reinforced structure means it can be used for waterproofing walls, floors & Ceilings while giving additional insulating properties.

Additionally the multi-board can be used for rigid boarding in partitions, wet rooms, loft conversions and performs as a great underlay for heated mats increasing overall efficiency.

Your Itinerary

In order to complete this how to guide, you're going to need the following product:

Marmox Multiboard	Marmox Washers
Marmox Reinforcing Tape	Marmox Waterproof Tape

Also

We suggest that you use the following accessories & safety equipment when undertaking this job:

[4Trade Safety Glasses](#)

[4Trade Super Grip Safety Gloves](#)

[4 Trade Respirator Mask](#)

Prior to installation it's important to ensure you are installing in a clean, dry environment that is well ventilated.

We strongly advise that you use Personal Protective Equipment (PPE) listed above.

Solid wall - dot & dab



Step 1

Create 5 fixing holes through the Marmox Multiboard.



Step 2

Put a dab of adhesive over the holes positions.



Step 3

Offer the Marmox Multiboard up to the wall, push firmly and then level with spirit level.



Step 4

Once the adhesive has dried drill the holes out. Place the white dowel in through into the wall and then hammer in the red pin.