



A bit of background

Marmox Multiboard can be used for many applications. Its premium quality, reinforced structure means it can be used for waterproofing walls, floors & Ceilings while giving additional insulating properties.

Additionally the multi-board can be used for rigid boarding in partitions, wet rooms, loft conversions and performs as a great underlay for heated mats increasing overall efficiency.

Your Itinerary

In order to complete this how to guide, you're going to need the following product:

| | |
|---|--|
| Marmox Multiboard | Marmox Washers |
| Marmox Reinforcing Tape | Marmox Waterproof Tape |

Also

We suggest that you use the following accessories & safety equipment when undertaking this job:

[4Trade Safety Glasses](#)

[4Trade Super Grip Safety Gloves](#)

[4 Trade Respirator Mask](#)

Prior to installation it's important to ensure you are installing in a clean, dry environment that is well ventilated.

We strongly advise that you use Personal Protective Equipment (PPE) listed above.

Solid wall - screw fixed



Step 1

Measure Marmox Multiboards and cut to size. Very easy to cut with a knife or saw.



Step 2

Marmox Multiboards can be fixed to solid wall with screws and washers at every 300mm. Alternatively use Marmox Fixing Dowels for ease.